



Motorola RAZR2 v9m Keypad Replacement

Replace a broken RAZR2 v9m keypad.

Written By: Sam Roach



INTRODUCTION

Use this guide to remove and install a keypad in a Motorola RAZR2 v9m.



TOOLS:

- [Spudger](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Battery



- Push the rear cover toward the hinge of the RAZR2. The panel will slide about 3 mm.

Step 2



- Pinch the top and bottom edges of the panel and pull it away from the RAZR2.

i The rear panel uses four small hooks to hold it in place. If the panel will not easily pull away, slide the panel more toward the hinge.

Step 3



- Gently pull the white plastic tab to lift the battery away from the RAZR2.
- ⓘ The white plastic tab is attached to the phone. Only pull it enough to expose the edges of the battery.

Step 4



- To remove the battery, grasp its edges pull away from the phone.
- ❗ When installing a new battery, be sure the metal contacts on the phone line up with the ones on the battery.

Step 5 — Keypad



- Flip the RAZR2 open with the battery compartment facing you.
- Pull the white battery tab away from the phone to reveal a small black gap in the battery compartment.
- Place the spudger into this gap. Rest the spudger against the black plastic inside of the gap.

Step 6



- Push the spudger into the phone until the top of the keypad pops out from the RAZR2.

Step 7



- Use a plastic opening tool to gently pry one side of the keypad away from the RAZR2.
- i** There are 2 clips on the side of the keypad. In total, there are 8 clips holding the keypad to the phone.

Step 8



- Lift the keypad away from the phone.

i When reassembling, gently squeeze the sides of the keypad until the keypad has a slight ridge running down the middle, like a playing card. This will ensure that it slides easily into place.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-06 09:05:34 PM.